

Z M C

ZIEMEK MILLING CENTER

Lava Shade Conversion Guide

B Vita Lumin Universal	3D-Master Vita	Chromascop Ivoclar	Ivoclar SR-Vivosit	Truebyte Bioform	Truebyte Bioblend	Lave Frame Shade
	OM1	010				FS1
	OM2	020				FS1
	OM3	030				FS1
A1	1M1	110-140	1A	B51	100	FS1
A2	2M2	110-140	1B	B53-62	104	FS3
A3	2R2.5	210-240	2A	B54-65	100	FS3
A3.5	3R2.5	210-240		B83		FS4
A4	4R2.5	510-540	3C	B84	118	FS4
B1	1M1	010/020/030	1A	B59		FS1
B2	2L1.5	100-140	2A	B52	104	FS2
B3	2M3	310-340	2B	B55-68	108	FS5
B4	3L2.5	310-340	2D-2C	B56	116	FS5
C1	2L2.5	410-440	1A	B91	100	FS2
C2	3L1.5	410-440	1C	B94	102-104	FS6
C3	3L1.5,4M2	510-540	4B-4C	B95	113-110	FS6
C4	5M1,5M2,5M3	510-540	3C	B96	114-116	FS6
D2	3M1,4M1,2R1.5	410-440		B92		FS7
D3	3M2	410-440		B93	108	FS7
D4	3R1.5	510-540	4B-6D	B69	110	FS7